

Cat-tape™

Silicone adhesive tape for sealing of edges of Catpad sheets

ShinEtsu
Shin-Etsu Silicone



Cat-tape™

Silicone adhesive tape for finishing of edges and overlapping sections of Catpad sheets.



Cat-tape cures and bonds in 24 hours after application, and bonds strongly to both Catpad sheets and mortar foundation surfaces.

No caulking gun or masking tape required, easy to work.


Can also be used to fill gaps, due to its putty-like consistency.

Less waste, which is better for the environment.

Packaging/Standard product size

● Packaging

Each roll comes in an aluminum moisture-proof pack.



● Standard product size

W25 mm × L3,000 mm

Comes with a pink separator film on one side. Pull off the separator film after applying the product to the substrate.




General properties

● Before curing (consistency of silicone putty)

Color	Separator film	Pink
	Tape	Light gray

Structure



● After curing (silicone rubber)

Parameters		Conditions	Curing time	Measured value	Remarks
Physical properties	Hardness	23°C/50%RH	8 days	45	JIS K 6249, A type
	Tensile strength			5.4 MPa	JIS K 6249
	Elongation			730%	
	Shear strength			16 kN/m	JIS K 6249, Angle type
Adhesion	On mortar	23°C/50%RH	8 days	22 N	Pulled in 180° direction, tape width: 10 mm
		40°C/95%RH		17 N	Pulled in 180° direction, tape width: 10 mm
	On Catpad	23°C/50%RH	8 days	47 N	Pulled in 180° direction, tape width: 10 mm Pulled off 50 with a jig using around 50 N of force.
	On Catpad		12 days	65 N	Pulled in 180° direction, tape width: 10 mm

(Not specified values)

Construction example and advantages of using Cat-tape



Cat-tape is designed for use with Catpad, and is used in many locations.

Construction examples

Sealing of overlapping Catpad sheets on outdoor tanks



Waterproofing of the bases of anchor bolt shafts and tops of boxes around outdoor tanks




Advantage:

Cat-tape is easier to work with than silicone sealants, and creates a finished look.

Construction examples


Joint inside a box culvert Catpad-cloth used to seal edges and overlap joints



Advantage:

Product was easy to use on ceilings.

In an underground water tank for firefighting Catpad used to seal edges, overlap joints and bases of ladder shafts



Advantage:

Sealing of edges of sheets and butt joints between sheets is easy, and construction took less time.

Construction procedure

Covering Catpad

Process 1

Surface preparation


Using power and hand tools, prepare the application surface by completely removing existing paint and rust to expose the metal beneath.



Process 2

Cleaning

Run your hand over the application surface to brush away small particles, etc.



Process 3

Eliminate moisture

Dry the application surface using a burner or blower. If use of such heat sources is restricted, dry thoroughly using a rag, etc.


● If the surface is too damp, Catpad will not adhere and bond to it properly.



Process 4

Covering Catpad

Take care that no air is trapped between the product and application surface. Use of a roller makes this easier. Be sure to press down firmly where sheets overlap. At this stage, the product should have a thick, gummy consistency, which can be checked by lifting the edge slightly.



* See the separate catalog for more information on Catpad.


Applying Cat-tape

Process 5

Cleaning

Clean the application surface with alcohol or similar and allow to dry.

- Do not use detergents.
- Do not touch the application surface with bare hands. Use of gloves is recommended. If textile gloves are worn, fibers may stick to the surface and degrade the bond.



Process 6

Applying Cat-tape

Open the package. Try to use up the product within about 30 minutes of opening the package.

● The product reacts with moisture in the air to bond/cure.


Starting with the overlaps, then cut with scissors once enough has been applied.



Process 7

Press down

Press down on the back of the separator film with the fingertips and then with a roller, making sure no spots are missed.



Process 8

Remove the separator

Slowly remove the separator film by pulling in a 180° direction.

- Be careful when removing the separator.
If the separator is pulled upward, the product may come up with it.



Process 9

Apply to edges

Apply to edges in the same manner.



Process 10

Press down


Be sure to press down firmly in places where pieces of tape overlap.



Process 11

Completed

Leave for 24 hours until the surface is cured, then the job is done.



Used with Catpad



Used with Catpad-cloth

Handling Precautions

1. Avoid working when there is water on the application surface. Make sure the surface is dry before starting work.
2. Clean the application surface of rust, debris, fibers, sand, small stones, oil, and water droplets. The Catpad surface can be cleaned with ethanol. Cleaning with detergents can have a negative effect on bonding, and should thus be avoided.
3. Once the aluminum moisture-proof pack is opened, the curing process begins as the product reacts with moisture in the air. All products in the pack should be used within 30 minutes of opening. Unused products cannot be saved for later use.
4. This product is not a low-molecular-weight siloxane reduction type. Do not use it for electronic applications.

Safety and hygiene

1. Uncured Cat-tape may cause skin irritation. When handling the products, take care to avoid contact with the skin and mucous membranes by wearing protective glasses and protective rubber gloves. In case of skin contact, immediately wipe off with dry cloth and then flush thoroughly with running water. In case of accidental eye contact, flush immediately with plenty of clean water and then seek medical attention. Contact lens wearers must take special care. If the products get into the eye, the contact lens may become stuck to the eye.
2. During curing, methyl ethyl ketone oxime (MEKO) is generated. Be sure there is adequate ventilation when handling this product. Avoid handling in a poorly ventilated area causing inhalation of vapors. If you feel ill after breathing the vapor, move immediately to an area with fresh air.
3. Keep out of reach of children.
4. Please read the Safety Data Sheet (SDS) before use. SDS can be obtained from our Sales Department.

Silicone Division Sales and Marketing Department Ⅲ

Marunouchi Eiraku Bldg., 4-1, Marunouchi 1-chome, Chiyoda-ku, Tokyo 100-0005, Japan
 Phone : +81-(0)3-6812-2409 Fax : +81-(0)3-6812-2415

Shin-Etsu Silicones of America, Inc.

1150 Damar Drive, Akron, OH 44305, U.S.A.
 Phone : +1-330-630-9860 Fax : +1-330-630-9855

Shin-Etsu do Brasil Representação de Produtos Químicos Ltda.

Rua Coronel Oscar Porto, 736 - 8º Andar - Sala 84,
 Paraíso São Paulo - SP Brasil CEP: 04003-003
 Phone : +55-11-3939-0690 Fax : +55-11-3052-3904

Shin-Etsu Silicones Europe B.V.

Bolderweg 32, 1332 AV, Almere, The Netherlands
 Phone : +31-(0)36-5493170 Fax : +31-(0)36-5326459
 (Products & Services: Products for Cosmetics Application)

Germany Branch

Kasteler Str. 45, 65203 Wiesbaden, Germany
 Phone : +49-(0)611-71187290
 (Products & Services: Products for Industrial Applications)

Shin-Etsu Silicone Korea Co., Ltd.

GT Tower 15F, 411, Seocho-daero, Seocho-gu,
 Seoul 06615, Korea
 Phone : +82-(0)2-590-2500 Fax : +82-(0)2-590-2501

Shin-Etsu Silicone Taiwan Co., Ltd.

Hung Kuo Bldg. 11F-D, No. 167, Tun Hua N. Rd.,
 Taipei, 105406 Taiwan, R.O.C.
 Phone : +886-(0)2-2715-0055 Fax : +886-(0)2-2715-0066

Shin-Etsu Singapore Pte. Ltd.

1 Kim Seng Promenade #15-05/06 Great World City,
 Singapore 237994
 Phone : +65-6743-7277 Fax : +65-6743-7477

Shin-Etsu Silicones Vietnam Co., Ltd.

Unit 4, 11th Floor, A&B Tower, 76A Le Lai Street,
 Ben Thanh Ward, District 1, Ho Chi Minh City, Vietnam
 Phone : +84-(0)28-35355270

Shin-Etsu Silicones India Pvt. Ltd.

Unit No. 403A, Fourth Floor, Eros Corporate Tower,
 Nehru Place, New Delhi 110019, India
 Phone : +91-11-43623081 Fax : +91-11-43623084

Shin-Etsu Silicones (Thailand) Ltd.

7th Floor, Harindhorn Tower, 54 North Sathorn Road,
 Silom Bangrak, Bangkok 10500, Thailand
 Phone : +66-(0)2-632-2941 Fax : +66-(0)2-632-2945

- The data and information presented in this catalog may not be relied upon to represent standard values. Shin-Etsu reserves the right to change such data and information, in whole or in part, in this catalog, including product performance standards and specifications without notice.
- Users are solely responsible for making preliminary tests to determine the suitability of products for their intended use. Statements concerning possible or suggested uses made herein may not be relied upon, or be construed, as a guaranty of no patent infringement.
- For detailed information regarding safety, please refer to the Safety Data Sheet (SDS).
- The silicone products described herein have been designed, manufactured and developed solely for general industrial use only; such silicone products are not designed for, intended for use as, or suitable for, medical, surgical or other particular purposes. Users have the sole responsibility and obligation to determine the suitability of the silicone products described herein for any application, to make preliminary tests, and to confirm the safety of such products for their use.

- Users must never use the silicone products described herein for the purpose of implantation into the human body and/or injection into humans.
- Users are solely responsible for exporting or importing the silicone products described herein, and complying with all applicable laws, regulations, and rules relating to the use of such products. Shin-Etsu recommends checking each pertinent country's laws, regulations, and rules in advance, when exporting or importing, and before using the products.
- Please contact Shin-Etsu before reproducing any part of this catalog. Copyright belongs to Shin-Etsu Chemical Co., Ltd.






The Development and Manufacture of Shin-Etsu Silicones are based on the following registered international quality and environmental management standards.

Gunma Complex	ISO 9001 (JCQA-0004)	ISO 14001 (JCQA-E-0002)
Naoetsu Plant	ISO 9001 (JCQA-0018)	ISO 14001 (JCQA-E-0064)
Takefu Plant	ISO 9001 (JQA-0479)	ISO 14001 (JQA-EM0298)